

NFPA-99 2005 Level 1 Area Alarm Points

This document is only to be used as a general alarm point guide. Refer to NFPA-99 2005 for detailed alarm point requirements

- high line pressure (for each gas piped to the area) 5.1.9.3
5.1.9.3.1
5.1.9.3.2
5.1.9.3.4

- low line pressure (for each gas piped to the area) 5.1.9.3
5.1.9.3.1
5.1.9.3.2
5.1.9.3.4

- low medical / surgical vacuum (if piped to the area) 5.1.9.3
5.1.9.3.1
5.1.9.3.3
5.1.9.3.4

- low WAGD vacuum (if piped to the area) 5.1.9.3
5.1.9.3.1
5.1.9.3.3
5.1.9.3.4