

Compression Principle:

Air is drawn into the compressor at the outer portion of the scroll.

The orbiting scroll moves inside of the fixed scroll.

The air is forced into progressively smaller chambers towards the center.

The compressed air is then discharged through the center of the fixed scroll.

No inlet or exhaust valves are needed.

